

# RadWagon



## User Guide Instructions

### SPECS

**Minimum Rider Height:**  
5' 1"

**Maximum Speed:**  
20 mph

**Estimated Range:**  
24-45+ miles

### OPERATION

**5 E-Bike Speeds:**  
Up/down arrow buttons on the left handle

**7 Gears - Rear Hub Only**  
Right handle

**Throttle**  
Right handle

**Front LED Headlight & Integrated Rear Light**  
operated from the display

Press and hold **mode button** to turn on/off.



Press **up/down arrow buttons** to change pedal assist level.

### Left Handle

Push the **up arrow and mode button at the same time** to activate the front headlight, the taillight, the brake light.

# POWER ON/OFF & CONTROLS

Press lever to shift gears "down" (easier to pedal, good for uphill).



Twist **downwards** to engage throttle.

### Right Handle


Press **+ button** to shift gears "up" (harder to pedal, good for downhill).



# ⚡ Screen Display

2: Trip Distance & Odometer. Use mode button to switch between odometer and trip distance.

1: Battery level



3: Current Speed

4: Pedal assist level (0-5). Press up/down arrows to change level.

Charging port

CHARGING & BATTERY

